

STAND.MOVE M2.0 ohne Speicherfunktion

Mit den Tasten AUF ▲ und AB ▼ kann die gewünschte Tischhöhe eingestellt werden. Die Funktion ist nur aktiviert, solange die Taste gedrückt bleibt.



Hinweis:

Die Canvaro Steh-Sitzarbeitsplätze mit elektromotorischer Höhenverstellung verfügen über eine Safety-Stop-Funktion. Dadurch wird das Verfahren nach unten automatisch 30 mm vor Erreichen der unteren Höhenposition gestoppt. Durch loslassen der AB-Taste und anschließend erneuter Betätigung (Funktion ist nur aktiviert, solange die Taste gedrückt wird) verfährt der Tisch dann mit halber Geschwindigkeit weiter bis zur unteren Position.

STAND.MOVE M2.1 mit Speicherfunktion (Memory) und LED-Display

Mit den Tasten AUF ▲ und AB ▼ kann die gewünschte Tischhöhe eingestellt werden. Die Funktion ist nur aktiviert, solange die Taste gedrückt bleibt.

Die Memorytasten 1, 2, 3 und 4 starten die Memoryfunktion und bewegen den Tisch in eine zuvor definierte Höhenposition. Dieser Befehl wird ebenfalls nur ausgeführt, solange die Taste gedrückt wird. Zum Speichern einer gewünschten Höhenposition auf das „ASSMANN“-Logo drücken und innerhalb von 2 Sekunden auf die gewünschte Ziffer drücken und loslassen.



Hinweis:

Die Canvaro Steh-Sitzarbeitsplätze mit elektromotorischer Höhenverstellung verfügen über eine Safety-Stop-Funktion. Dadurch wird das Verfahren nach unten automatisch 30 mm vor Erreichen der unteren Höhenposition gestoppt. Durch loslassen der AB-Taste und anschließend erneuter Betätigung (Funktion ist nur aktiviert, solange die Taste gedrückt wird) verfährt der Tisch dann mit halber Geschwindigkeit weiter bis zur unteren Position.

STAND.MOVE M2.0 without memory function

The required desk height is set with the UP ▲ and DOWN ▼ buttons. The function remains active until the button is released.



Please note:

The Canvaro stand-up/sit-down desks with height adjustment driven by an electric motor come with a safety-stop feature. This stops the move downwards automatically 30mm before reaching the lowest position. Releasing the DOWN key and then pressing it again (feature is only activated for as long as the key is pressed), causes the desk to continue moving to the lowest position at half speed.

STAND.MOVE M2.1 with memory function and LED display

The required desk height is set with the UP ▲ and DOWN ▼ buttons. This function is only active as long as the key is pushed.

The memory keys 1, 2, 3 and 4 activate the memory function and the desk moves to the previously defined height position. This function is also only active as long as the key is pushed. To save a desired height position, press the „ASSMANN“ logo, and then within 2 seconds press and release the desired number.



Please note:

The Canvaro stand-up/sit-down desks with height adjustment driven by an electric motor come with a safety-stop feature. This stops the move downwards automatically 30mm before reaching the lowest position. Releasing the DOWN key and then pressing it again (feature is only activated for as long as the key is pressed), causes the desk to continue moving to the lowest position at half speed.